

Item Number
RAM-VB-101

RAM No-Drill Seat Bases

National Products, Inc.

Vehicle base for the
Chevy S10 (1995-Newer)
S10 Blazer (1995-Newer)
GMC Sonoma (1995-Newer)
Jimmy (1995-Newer)

INSTALLATION INSTRUCTIONS

1. Place both front seats of the vehicle in their most rearward position.
2. Remove the following fasteners that hold the seats down to the vehicle floor: Front right seat fastener on driver's side, and front left seat fastener on passenger's side.
3. While lifting seat up slightly, slide the No Holes Drilled Base in-between the vehicle floor and the seat. The platform portion of the base should be positioned toward the front of the vehicle.
4. Line up the holes, (some Bases have slots which allow adjustment front-to back or side-to-side), reinstall the seat fasteners and tighten, securing both seat and base to vehicle floor.

National Products, Inc.
Phone: 206-763-8361
Fax: 206-763-9615
Address: 1205 S Orr St
Seattle, WA 98108
Website: www.ram-mount.com
Email: staff@ram-mount.com

