

Item Number
RAM-VB-171

RAM No-Drill™ Seat Bases

RAM Mounting Systems

Vehicle base for the **TOYOTA PRIUS (2007-2009)**

SPECIFICATIONS

Placement

Passenger side on the floor, under front seat

Drilling Required

No - uses existing seat bolts

Seat Configuration

Bucket

Pole or Pedestal

Sold Separately

Construction/Finish

Steel/Black Powdercoat

Weight

N/A

Dimensions

A = 18", B = 7", C = 2.85"
Hole Center = 15.44"

Features


Installs in minutes with no drilling required
Low profile keeps mount away from passenger leg space

Misc.

Rock solid construction
Lifetime warranty



Shown In Use



RAM-VB-171

RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-171

Item Number
RAM-VB-171

RAM No-Drill™ Seat Bases

RAM Mounting Systems

Vehicle base for the **TOYOTA PRIUS (2007-2009)**

INSTALLATION INSTRUCTIONS

1. Move the passenger seat back to its rearmost position and remove the front seat rail bolts using a 14MM wrench..
2. Without moving the seat, place the No-Drill™ base over the front of the seat bracket.
3. Align the holes in the No-Drill™ base with the holes in the seat frame legs.
4. Pass the seat bolts through the holes and start the threads by hand.
5. Once bolt has begun to thread into the hole, use the 14MM wrench for fully re-tighten the seat bolts.
6. After about a week of use, check seat bolts and re-tighten if necessary.

RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-171